



STANG MOTORSPORTS
780.979.0299
www.stangmotorsports.ca

Installation Instructions

Body Colored Radiator Cover



Step 1 Pull out the 6 push pin fasteners in the locations shown above. The pins are removed by prying up the head in the center and then pulling them out.

Step 2 Remove the old radiator cover by pulling the front lip out and then lifting off.

Step 3 Place the new radiator cover in place making sure the front edge is under the flange. Line up the holes for the push pins.

Step 4 Replace the push pin fasteners by placing them in the mounting holes and then pushing the heads down until flush.

Questions? We can be reached by e-mail
sales@stangmotorsports.ca or by phone: **780.979.0299**